

1. Insert a 9V battery in the compartment.
2. Set **POWER** to **ON**.
3. Set the vibration sensor switch to **H**, **M**, or **L** (high, medium, or low).

Place the doorstop alarm on the floor, with the wedge end facing the closed door, about ½-inch behind the closed door. If the doorstop alarm is wedged under the door when it opens, the alarm may not sound.

4. If the door is opened, the bottom edge of the door presses down on the wedge plate and sets off the alarm. The alarm sounds for 30 seconds, then shuts off. To silence it sooner, set **POWER** to **OFF**.



To save battery power, set **POWER** to **OFF** when the alarm is not in use.

If the siren sounds weak or the alarm stops operating properly, the battery might be low. Replace the battery.

BATTERY NOTES

- Dispose of old batteries promptly and properly.
- Do not burn or bury batteries.
- Use only fresh batteries of the required size and recommended type.
- Do not mix old and new batteries, different types of batteries (standard, alkaline, or rechargeable), or rechargeable batteries of different capacities.
- If you do not plan to use the doorstop alarm for a week or more, remove the batteries. Batteries can leak chemicals that can destroy electronic parts.